Visiosense

wPUSH

Key features

The wPush interface on smartphone or tablet can transmit photos or videos instantly by reacting to an event.
Examples: Live broadcast of a sporting feat on your screens.

To broadcast a media:

1- enter my username and password

2- select the media in my files

3- send it to the active list

I can program the time of passage on the screen. A pre-established configuration at the server level, defines the number of media as well as the location on the screen: full screen, zones, central or local space.

UN ESPACE RESERVE A LA COMMUNICATION CENTRALE

UN ESPACE RESERVE AUX ADHERENTS *flasher!*

Prenez une photo ou une vidéo
et
Publiez la

1   2   3

Example:
simple screen
2 zones 1 banner

Possibility
4 zones and 4 banners

TEN NIS   TEN NIS

Aujourd'hui match à 14h

Announced banner with QR code and clock

INTERFACE SMARTPHONE

The mobile application is directly accessible on a browser via a QR code or a server address.

Securing
Login and password

Since wPush direct access to smartphone resources: camera, gallery, files, etc …

Activated media can to be added, deleted or programmed

Identifiant:

Mot de passe:

Valider

OUVRIR À PARTIR DE

Téléchargements

Carte SD
Espace disponible : 38,94...

Drive

Drive

Drive

Photos

OneDrive

Sélection de sons

Galerie

Gestionnaire de fichiers...

Déposez votre média

1:	tennis-courts-in-autumn_4460x4460.jpg	00:10
2:	kite-surfer_4460x4460.jpg	00:10
3:	basketball_4460x4460.jpg	00:10
4:	drone-birds-eye-photo-of-striker-kicking p...	00:10
5:	golfer-lines-up-at-driving-range_4460x44...	00:10
6:	arrow-feathers_4460x4460(1).jpg	00:10

admin   29/01/2019 16:43:19